

RP Meter Replacement Guide

RG-IP-RP3-METER-Q216V1



⚠ Attention

1 Before asking for your RP meter replacement, please complete the following:

- Provide your PDU *serial number* and *outlet configuration*
- This information is **absolutely necessary** for the new replacement meter.
- Otherwise, the replacement meter will not work.

2 All electrical power and power control wiring must be installed by a qualified electrician and comply with local and national regulations.



Step 1: Mark down the PDU level number

- If the meter fails to display, check this with your administrator.



Step 2: Disconnect LAN Cable & Sensor Cable

- Remove and save the RackPower label from the existing meter. You will be placing it on the new meter after it is installed.


- ⚠ RP meter field replaceable design facilitates the replacement. PDU power disconnection is **NOT** required.
- ⚠ Because of LAN cable disconnection, the management software will keep sending alarms via email about PDU disconnection. Just ignore this. Email alarms will stop upon meter reconnection.



Step 3: Unscrew and pull out the faulty RP meter



Step 4: Place the new meter & secure with screws



HOW TO REPLACE THE RP METER




Step 5: Power on the PDU
 - Set the PDU level according to Step 1



Step 6: Place the previous RackPower sticker on the new meter.
 - Reconnect LAN Cable & Sensor Cable


⚠ RP meter field replaceable design facilitates the replacement. PDU power disconnection is **NOT** required.

⚠ Because of LAN cable disconnection, the management software will keep sending alarms via email about PDU disconnection. You can ignore the email. Email alarms will stop upon meter reconnection.



Step 7: Go to RPM-04 < Status > page
 - Click "Start Connection"

⚠ This step is only required for 1st level PDU(s).



Step 8: Update the PDU Details in software

• Such as PDU name, location, alarm threshold

END



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN RAYCHEM SCHROFF TRACER

©2018 nVent. All nVent marks and logos are owned or licensed by nVent Services GmbH or its affiliates. All other trademarks are the property of their respective owners. nVent reserves the right to change specifications without notice.

H84280_1809

[nVent.com/SCHROFF](https://www.nvent.com/SCHROFF)